

Grozone Control

CO2R / SCO2 / CO2D Alarm and Error Meanings

Alarm / Error #	Description	Displayed on Screen
Error 1	CO2 Sensor problem: turn power off and retry. If problem persists, call your retailer.	CO2 and SCO2: «Er. 1» CO2D: «----»
Error 3	Real Time Clock problem (CO2D only): turn power off and retry. If problem persists, call your retailer.	«Er.3» Alternately with sensor values
Error 8	Memory corruption problem: all settings have been reset to factory settings. You may need to re-enter your settings. If problem persists, call your retailer.	«Er.8» Alternately with sensor values

Significations des alarmes et erreurs CO2 / SCO2 / CO2D

No Alarme / erreur	Description	Affichage à l'écran
Erreur 1	Problème du capteur de CO2 : Déconnecter le contrôleur et rebrancher. Si le problème persiste, appelez votre magasin.	CO2 et SCO2: «Err1» CO2D: «----»
Erreur 3	Problème avec l'horloge. (HTC seulement). Déconnecter le contrôleur et reconnecter. Si le problème persiste, appelez votre magasin.	«Er.3 » alterne avec les valeurs des capteurs.
Erreur 8	Corruption de la mémoire. Tous les paramètres ont été réinitialisés avec les valeurs initiales par défaut. Vous pouvez avoir besoin de reprogrammer votre contrôleur. Si le problème persiste, appelez votre magasin.	«Er.8 » alterne avec les valeurs des capteurs.