TROUBLESHOOTING THE CY3 GROZONE – DIGITAL CYCLE TIMER WITH DISPLAY Procedure Name: CY3-V2

1 – BEFORE YOU START * CAUTION : READ AND FOLLOW THESE DAY OFF Time NIGHT ON Time INSTRUCTIONS BEFORE STARTING THE TEST Indicator Indicator DO NOT CONNECT UNIT BEFORE STEP 1 OF THE TEST. ٠ ••• CONNECT A LOAD INTO THE FRONT OUTLET OF THE UNIT. LIGHTHING CONDITION: perform this test in a room ••• DAY ON Time NIGHT OFF Time Light Senso with enough light for the unit to detect a DAY Indicator Indicator condition. Click knob to select and NOTE: read ON times on the LEFT scale and OFF times on the RIGHT turn to set values scale. 2 – TEST STEP **EXPECTED RESULTS** HANDLING AND TEST DESCRIPTION When power is applied, each bar of the display is lit individually from bottom to top and back to bottom. * Plug the unit into the power outlet. 1 DAY ON time Indicator is BLINKING. Load connected to 120V front outlet is ON. DAY ON time indicator is STEADY LIT. Click knob once to enter cycle settings ٠ 2nd bar of display (from bottom) is STEADY LIT. ٠ Turn knob to set DAY ON time to 10 2 seconds (2nd bar is lit). The load connected to 120V front outlet will remain in the same state it was (ON or OFF, when cycle setting was entered). Time countdown is suspended. $\dot{\mathbf{v}}$ Click knob once NIGHT ON time indicator is STEADY LIT. ••• Turn knob to set NIGHT ON time to 60 3 6th bar of display (from bottom) is STEADY LIT. seconds (6th bar is lit). ∻ Click knob once DAY OFF time indicator is STEADY LIT. ٠ Turn knob to set DAY OFF time to 1 Δ 1st bar of display (from bottom) is STEADY LIT. minute (1st bar is lit). ٠ Click knob once NIGHT OFF time indicator is STEADY LIT. 5 ••• Turn knob to set NIGHT OFF time to 10 4th bar of display (from bottom) is STEADY LIT. minutes (4th bar is lit). DAY ON time or DAY OFF time indicator is BLINKING, meaning ON or OFF time countdown is underway. Click knob once to resume normal ••• The unit will cycle 10 seconds ON followed by 1 minute OFF. Observe 6 operation. one complete ON-OFF cycle and verify ON and OFF times. LOAD must be ON when either DAY ON time or NIGHT ON time indicator is lit.

7	the palm of your hand or black electrical	DAY OFF time and DAY ON time indicators (i.e. both "Sun" icons) turn OFF. NIGHT OFF time indicator starts BLINKING and 4 th bar turns ON.
8	until DAY condition is met.	4 th bar turns OFF. NIGHT OFF time and NIGHT ON time indicators (i.e. both "Moon" icons) turn OFF. DAY ON time indicator starts BLINKING and 2 nd bar turns ON.